

The background is a dark blue gradient. It features several light blue circular icons representing different moon phases: a full moon, a waxing crescent, a first quarter, a waning gibbous, and a thin crescent. These icons are scattered across the page. Additionally, there are faint constellation-like patterns consisting of small circles connected by thin lines, resembling a star map.

# *Collection Moon*

— Phases de lune —

**MODE  
D'EMPLOI**



**Position I :** Position de repos (la montre fonctionne).

**Position II :** Correction rapide de la date.

**Position III :** Réglage de l'heure et des phases de lune.

## Réglage de l'affichage de la phase de lune

Pour le réglage de l'affichage de la phase de lune, aucune possibilité de correction rapide.

- Tirer la couronne en position III (la montre s'arrête).
- Tourner les aiguilles en avant par la couronne, jusqu'à ce que la phase de lune actuelle s'affiche.
- Repousser la couronne en position I.

Conseil : Il est plus facile de régler sa montre lors de la pleine lune.

## Dates de pleine lune

	J	F	M	A	M	J	J	A	S	O	N	D
<b>2021</b>	28	27	28	27	26	24	24	22	21	20	19	19
<b>2022</b>	18	16	18	16	16	14	13	12	10	9	8	8